

## HP Pilot/SAR Suit Size Guide Regular sizes




Fig. 1

### Example of how to determine suit size

Point	Description	XXS/02	XS/03	S/04	M/05	L/06	XL/07	XXL/08
A	1/1 Chest (total circumference)	90 - 102	94 - 105	100 - 111	106 - 118	112 - 124	118 - 131	125 - 137
B	1/1 Waist (total circumference)	76 - 94	81 - 99	85 - 103	92 - 110	99 - 117	104 - 123	112 - 130
C	1/1 Widest measurement between waist and crotch	87 - 98	93 - 103	98 - 110	106 - 117	113 - 124	120 - 131	128 - 139
D	Torso	140 - 160	149 - 169	159 - 179	168 - 188	178 - 198	188 - 208	198 - 217

Size L/06

Fig. 2

1. Please record all measurements according to figure 1
2. Record measurements in size table below.
3. Suit size is determined by size column with highest registered measurement, see figure 2.

Point	Description	XXS/02	XS/03	S/04	M/05	L/06	XL/07	XXL/08
A	1/1 Chest (total circumference)	90 - 102	94 - 105	100 - 111	106 - 118	112 - 124	118 - 131	125 - 137
B	1/1 Waist (total circumference)	76 - 94	81 - 99	85 - 103	92 - 110	99 - 117	104 - 123	112 - 130
C	1/1 Widest measurement between waist and crotch	87 - 98	93 - 103	98 - 110	106 - 117	113 - 124	120 - 131	128 - 139
D	Torso	140 - 160	149 - 169	159 - 179	168 - 188	178 - 198	188 - 208	198 - 217

Note: All measurements should be taken wearing close fitting clothes only. Use a "tailor's" (flexible) tape for all measurements. Measurements should be taken in centimeters.